


If your Orora Rom is not functioning correctly and you are seeing this



you may have change the program. Follow these steps to reset the Orora to factory default settings.

Method

1. Enter the program mode with a long push (3 sec) on the button.



Once you are in program mode you will see on the display:




2. Short push (1 sec) the button 7 times to display:



3. Long push the button once to display:



4. Long push the button again the lightning bolt will be flashing:



5. Short push once to display:



6. Long push once to display:



7. Short push once to display:



8. Short push to display



9. Disconnect both battery and solar power and wait 30 sec. Reconnect battery power then reconnect solar power.

10. The regulator is now reset to factory default settings.